

STL Wiring Update Alert

Please be advised that some of the old Microtima DIN Rail mounted housings were labelled incorrectly with the polarities of the outputs the wrong way around. The two diagrams below show correctly how the STL-MB and STL LB models should actually be connected.

